Fire Alarm

Hardware Requirements:

- 1) Flame sensor (Analogue Output) (1)
- 2) Arduino (1)
- 3) Bread board (1)
- 4) LED- (2)
- 5) Buzzer (1)
- 6) Connecting wires (as per need)

Connection:

Flame sensor to Arduino:

vcc -> vcc

gnd -> gnd

A0 -> A0

Led interfacing to Arduino


LED +ve is connected to **9th pin** of Arduino

LED -ve is connected to **gnd pin** of arduino**Buzzer interfacing to Arduino**

Buzzer +ve is connected to 12th pin of Arduino

Buzzer -ve is connected to GND pin of Arduino

Result:



As we will bring flame near to flame sensor, the buzzer will buzz on and u will be warned for the flame detection.